



# Posey® Wheelchair Wing-Backs

## Posey Wheelchair Wing-Backs

These lateral supports provide firm, stable support for patients who lean laterally. The angle of attachment may be adjusted manually to accommodate the needs of the individual patient/ resident. Made of firm 1/4" wood covered with thick foam and a water-repellent vinyl cover. The Posey Wheelchair Wing-Backs install in seconds using the existing screws for the vinyl wheelchair backrest. Measures 8"W x 10"L.

- Meets CA #117 flame retardency standards.
- Wipe-clean vinyl cover.
- One pair per package.

**Cat. #6321**

### Application Instructions:

1. Remove the top two screws on each side of the vinyl wheelchair backrest.
2. Orient the Posey Wing so that the screw holes in the metal brackets line up with the screw holes of the backrest. The Wing should be positioned so that it lays on top of the wheelchair armrest.
3. Attach the screws so that the seat back and the Posey Wing are both secure.

The angle of the Posey Wing may be adjusted by applying pressure to the metal bracket and bending it slightly. To avoid damaging the Posey Wing, be sure to brace the whole product with your hand before applying pressure to the metal bracket.



**J.T. Posey Company** 5635 Peck Road • Arcadia, CA 91006-0020 USA • Tel: 800-447-6739 or 626-443-3143 • Fax: 800-767-3933 or 626-443-5014 • www.posey.com

© 1995 J.T. Posey Company. All rights reserved.

EU AUTH. PERSON: (MDD 93/42/EEC) MDSS GmbH, Burckhardtstr. 1, D-30163, Hannover, Germany



M1638 05260C



# Posey® Wheelchair Wing-Backs

## Posey Wheelchair Wing-Backs

These lateral supports provide firm, stable support for patients who lean laterally. The angle of attachment may be adjusted manually to accommodate the needs of the individual patient/ resident. Made of firm 1/4" wood covered with thick foam and a water-repellent vinyl cover. The Posey Wheelchair Wing-Backs install in seconds using the existing screws for the vinyl wheelchair backrest. Measures 8"W x 10"L.

- Meets CA #117 flame retardency standards.
- Wipe-clean vinyl cover.
- One pair per package.

**Cat. #6321**

### Application Instructions:

1. Remove the top two screws on each side of the vinyl wheelchair backrest.
2. Orient the Posey Wing so that the screw holes in the metal brackets line up with the screw holes of the backrest. The Wing should be positioned so that it lays on top of the wheelchair armrest.
3. Attach the screws so that the seat back and the Posey Wing are both secure.

The angle of the Posey Wing may be adjusted by applying pressure to the metal bracket and bending it slightly. To avoid damaging the Posey Wing, be sure to brace the whole product with your hand before applying pressure to the metal bracket.



**J.T. Posey Company** 5635 Peck Road • Arcadia, CA 91006-0020 USA • Tel: 800-447-6739 or 626-443-3143 • Fax: 800-767-3933 or 626-443-5014 • www.posey.com

© 1995 J.T. Posey Company. All rights reserved.

EU AUTH. PERSON: (MDD 93/42/EEC) MDSS GmbH, Burckhardtstr. 1, D-30163, Hannover, Germany



M1638 05260C